



CANTERBURY  
LANDSCAPE  
SUPPLIES

1250 Main North rd  
Bridgend  
Christchurch

T. 03-323-7797  
F. 03-323-7697  
sales@pottingmix.co.nz  
www.pottingmix.co.nz

## Putting down a new driveway:

1. Dig out the area you want.
2. Fill in 200-250mm of AP65 basecourse
3. Roll over this and flatten it out
4. Put 50-100mm of AP20 Topcourse
5. Make sure it is moist, but not too wet and compact it all down.

You will need at least 300mm to make a stable driveway